2. Power Window System

A: WIRING DIAGRAM

1. POWER WINDOW

<Ref. to WI-143, WIRING DIAGRAM, Power Window System.>

B: INSPECTION

Symptom	Repair order
All power windows do not operate.	Fuse (SBF-6) (F/B No. 18) Power window circuit breaker Power window relay
	4. Wiring harness
Particular window does not operate.	 Power window main switch Power window sub switch Power window motor Wiring harness
"Window Lock" does not operate.	Power window main switch