

General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

3. General Description

A: CAUTION

1) If the seat cushion cover is removed or replaced, make sure to perform occupant detection system adjustment after installing the seat to the vehicle. <Ref. to OD(TYPE B)(diag)-18, SYSTEM CALIBRATION (REZEROING), OPERATION, Subaru Select Monitor.>

Failure to do so may cause improper operation of the occupant detection system.

2) The occupant detection system (passenger seat only) control module and the occupant detection sensor are fixed to the seat cushion frame. Never remove the occupant detection control module or the pressure sensor from the seat cushion frame.

3) Do not replace the seat cushion pad by itself. Always replace the seat cushion pad and frame assembly as a set. The seat cushion pad and cushion frame are adjusted as a set at the time of manufacture. If cushion pads and cushion frames are combined from those of other vehicles or other sets, the occupant detection system may not operate properly.

4) If the seat cushion cover is removed, make sure to replace the wire on the seat cushion side with a new wire.

5) Never connect the battery in reverse polarity. Occupant detection system may be destroyed instantly.

6) Do not disconnect the battery terminals while the engine is running. A large counter electromotive force will be generated in the generator, and this voltage may damage electronic parts such as occupant detection control module.

7) Before disconnecting the connectors of each sensor and control module, be sure to turn the ignition switch to OFF and wait for 20 seconds or more. Occupant detection control module may be damaged.

8) All occupant detection system parts are precision components. Do not drop them.

CAUTION:

- **Airbag system connectors are yellow. Do not use electrical test equipment on these circuits.**
- **Be careful not to damage the airbag system wiring harness when servicing the occupant detection system.**
- **Refer to "Airbag System" when repairing the occupant detection system. <Ref. to AB-3, CAUTION, General Description.>**

B: INSPECTION

Measure the battery voltage and specific gravity and check electrolyte.

Standard voltage: 12 V or more

Specific gravity: Above 1.260

Fluid level: Between the upper level and lower level

General Description


OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

C: PREPARATION TOOL

CAUTION:

To measure the voltage and resistance of airbag system and occupant detection system components, be sure to use the specified test harness.


1. SPECIAL TOOL


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST18482AA010	18482AA010	CARTRIDGE	Used for diagnosis of the electrical system.
 ST22771AA030	22771AA030	SUBARU SELECT MONITOR KIT	Used for diagnosis of the electrical system.

General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)


TEST HARNESS D

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	98299AG060 ST98299AG060	TEST HARNESS D	Used when measuring the voltage and resistance of the front seat belt buckle switch.




AB-01068

TEST HARNESS U

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	98299AG000 ST98299AG000	TEST HARNESS U	Used when measuring voltage and resistance of airbag control module.

General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)





AB-00930

General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

TEST HARNESS Y


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	98299AG040	TEST HARNESS Y	Used for diagnosing the seat belt buckle switch.




General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

TEST HARNESS AB


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	98299XA000 ST98299XA000	TEST HARNESS AB	Used when measuring voltage and resistance of occupant detection system.




General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

TEST HARNESS AE

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299XA030	98299XA030	TEST HARNESS AE	Adapter harness of TEST HARNESS Y Used for diagnosing the seat belt buckle switch.





OD-00026

General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

TEST HARNESS AC

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299XA010	98299XA010	TEST HARNESS AC	Used for diagnosing the seat belt tension sensor.





OD-00027

General Description

OCCUPANT DETECTION SYSTEM (TYPE B) (DIAGNOSTICS)

TEST HARNESS AD

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST98299XA020	98299XA020	TEST HARNESS AD	Used when measuring voltage and resistance of the seat belt tension sensor.



OD-00028

2. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance, voltage and current.