


Front ABS Wheel Speed Sensor

ABS


4. Front ABS Wheel Speed Sensor

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Disconnect the ABS wheel speed sensor connector located next to the front strut mounting house in the engine compartment.
- 3) Remove the bolts which secure the sensor harness to the strut.



- 4) Remove the bolts which secure sensor harness to the body.




- (1) To the front ABS wheel speed sensor connector
- (2) Bracket

- 5) Remove the bolts which secure front ABS wheel speed sensor to the housing, and remove the front ABS wheel speed sensor.

CAUTION:

- Be careful not to damage the pole piece and the face of the teeth located at tip of the sensor during removal.
- Do not pull on the sensor harness during removal.




B: INSTALLATION

- 1) Temporarily install the front ABS wheel speed sensor on the housing.

CAUTION:


- Be careful not to hit the ABS wheel speed sensor pole piece and tone wheel against adjacent metal parts during installation.



- 2) Install the front ABS wheel speed sensor on the strut and the wheel apron bracket.

Tightening torque:

33 N·m (3.4 kgf·m, 24.6 ft·lb)




- (1) To the front ABS wheel speed sensor connector
- (2) Bracket

3) Check the clearance of the sensor. <Ref. to ABS-15, SENSOR GAP, INSPECTION, Front ABS Wheel Speed Sensor.>

If clearance is outside of the standard value, readjust by using the spacer (Part No. 26755AA000).

ABS wheel speed sensor gap standard value:
0.3 — 0.8 mm (0.012 — 0.031 in)

Tightening torque:
33 N·m (3.4 kgf·m, 24.6 ft·lb)



NOTE:

Check the identification (mark) on the harness to make sure there is no warpage. (RH: Light blue, LH: Brown)

4) After confirmation of the ABS wheel speed sensor clearance, connect the connector to the ABS wheel speed sensor.

5) Connect the ground cable to the battery.


C: INSPECTION

1. ABS WHEEL SPEED SENSOR

1) Check the pole piece of the ABS wheel speed sensor for foreign particles or damage. If necessary, clean the pole piece or replace the ABS wheel speed sensor.

2) Measure the ABS wheel speed sensor resistance.

If resistance is outside the standard value, replace with a new ABS wheel speed sensor.




Terminal No.	Specification
1 and 2	1.25±0.25 kΩ

NOTE:

Check the ABS wheel speed sensor cable for discontinuity. If necessary, replace with a new one.

2. SENSOR GAP


1) Measure the distance “A” between the ABS wheel speed sensor surface and sensor pole face.



2) Measure the distance “B” between the surface where the front axle housing meets the ABS wheel speed sensor, and the tone wheel.

NOTE:

Measure so that the gauge touches the apex of the tone wheel teeth.



- (1) Axle housing
- (2) Tone wheel

3) Find the gap between the ABS wheel speed sensor pole face and the surface of the tone wheel teeth by entering and calculating the measured values in the formula below.

ABS wheel speed sensor gap = B – A

ABS wheel speed sensor gap standard value:
0.3 — 0.8 mm (0.012 — 0.031 in)

NOTE:

If clearance is outside of the standard value, readjust by using the spacer (Part No. 26755AA000).

Front ABS Wheel Speed Sensor

ABS

3. OUTPUT VOLTAGE


Output voltage can be checked by the following method. Install a resistor and condenser, then rotate the wheel about 2.75 km/h (2 MPH) or equivalent.

Standard value of output voltage:

0.12 — 1 V (at 20 Hz)

NOTE:

Regarding terminal numbers, please refer to item 1. ABS WHEEL SPEED SENSOR. <Ref. to ABS-15, ABS WHEEL SPEED SENSOR, INSPECTION, Front ABS Wheel Speed Sensor.>



(1) Oscilloscope

(2) Terminals

D: ADJUSTMENT

Adjust the gap using spacers (Part No. 26755AA000).