7. General Diagnostic Table

A: INSPECTION

NOTE:

Vibration while cruising may be caused by an unbalanced tire, improper tire inflation pressure, improper wheel alignment, etc.

| Symptom | Possible cause | Corrective action |
|---|-----------------------------|---|
| Noise or vibration from propeller shaft | Center bearing | Check the center bearing. <ref. bearing="" center="" ds-15,="" free="" inspection,="" play,="" propeller="" shaft.="" to=""></ref.> |
| | Runout of propeller shaft | Check for deflection of the propeller shaft. <ref. ds-<br="" to="">14, RUNOUT OF PROPELLER SHAFT, INSPECTION, Propeller Shaft.></ref.> |
| | Loose or gap at connections | Check the joints and connectors. <ref. and="" connections,="" ds-14,="" inspection,="" joints="" propeller="" shaft.="" to=""></ref.> |
| | | Check the spline and bearing. <ref. and="" bearing="" ds-14,="" inspection,="" locations,="" propeller="" shaft.="" splines="" to=""></ref.> |
| Abnormal wheel vibration | Wheel is out of balance. | Check the wheel balance. <ref. adjust-ment,="" balancing.="" to="" wheel="" wt-7,=""></ref.> |
| | Wheel alignment | Check the wheel alignment. <ref. alignment.="" fs-5,="" inspection,="" to="" wheel=""></ref.> |
| | Front strut | Check the front strut. <ref. front="" fs-18,="" inspection,="" strut.="" to=""></ref.> |
| | Rear strut | Check the rear strut. <ref. inspection,="" rear="" rs-12,="" strut.="" to=""></ref.> |
| | Front drive shaft | Check the front drive shaft. <ref. drive="" ds-34,="" front="" inspection,="" shaft.="" to=""></ref.> |
| | Rear drive shaft | Check the rear driveshaft. <ref. drive="" ds-40,="" inspection,="" rear="" shaft.="" to=""></ref.> |
| | Front axle | Check the wheel alignment. <ref. axle.="" ds-21,="" front="" inspection,="" to=""></ref.> |
| | Rear axle | Check the rear axle. <ref. axle.="" ds-29,="" inspection,="" rear="" to=""></ref.> |
| Noise from the underbody | Wheel is out of balance. | Check the wheel balance. <ref. adjust-ment,="" balancing.="" to="" wheel="" wt-7,=""></ref.> |
| | Wheel alignment | Check the wheel alignment. <ref. alignment.="" fs-5,="" inspection,="" to="" wheel=""></ref.> |
| | Front strut | Check the front strut. <ref. front="" fs-18,="" inspection,="" strut.="" to=""></ref.> |
| | Rear strut | Check the rear strut. <ref. inspection,="" rear="" rs-12,="" strut.="" to=""></ref.> |

ABS

ABS

| | | Page |
|----|---|------|
| 1. | General Description | 2 |
| 2. | ABS Control Module and Hydraulic Control Unit (ABSCM&H/U) | 6 |
| | ABS Sequence Control | |
| | Front ABS Wheel Speed Sensor | |
| | Rear ABS Wheel Speed Sensor | |
| | Front Tone Wheel | |
| | Rear Tone Wheel | |
| | G Sensor | |