
1. General Description

A: SPECIFICATION

Model		Rear drum brake	Rear disc brake
Туре		Rear brake mechanical	Mechanical, drum in disc rear brakes
Effective drum diameter	mm (in)	228.6 (9)	170 (6.69)
Lining dimensions (Length×Width×Thickness)	mm (in)	219.4 × 35.0 × 4.1 (8.64 × 1.378 × 0.161)	163.1 × 30.0 × 3.2 (6.42 × 1.181 × 0.126)
Clearance adjustment		Automatic adjusting	Manual adjustment
Lever stroke	notches/N (kgf, lb)	7 — 8/196 (20, 44)	

B: COMPONENT

1. PARKING BRAKE (REAR DISC BRAKE)




- (1) Back plate
- (2) Retainer
- (3) Spring washer
- (4) Lever
- (5) Parking brake shoe (Primary)
- (6) Parking brake shoe (Secondary)
- (7) Strut spring

- (8) Strut
- (9) Shoe guide plate
- (10) Primary return spring
- (11) Secondary return spring
- (12) Adjusting spring
- (13) Adjuster
- (14) Shoe hold-down cup

- (15) Shoe hold-down spring
- (16) Shoe hold-down pin
- (17) Adjusting hole cover

Tightening torque: N-m (kgf-m, ft-lb)

2. PARKING BRAKE CABLE



- (1) Parking brake lever
- (2) Parking brake switch
- (3) Self-locking nut
- (4) Clamp (Rear disc brake model only)
- (5) Equalizer
- (6) Bracket
- (7) Clamp
- (8) Parking brake cable RH
- (9) Cable guide

(10) Parking brake cable LH

Tightening torque: N·m (kgf-m, ft-lb)

T1: 18 (1.8, 13.0) T2: 32 (3.3, 23.6)

C: CAUTION

- Wear work clothing, including a cap, protective goggles and protective shoes during operation.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Be careful not to burn your hands, because each part on the vehicle is hot after running.
- Use SUBARU genuine grease etc. or equivalent. Do not mix grease etc. with that of another grade or from other manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Before securing a part in a vise, place cushioning material such as wood blocks, aluminum plate or cloth between the part and the vise.
- Make sure grease does not come into contact with the parking shoes.