

### 3. Rear Catalytic Converter

#### A: REMOVAL

The rear catalytic converter is integrated into center exhaust pipe as one unit; therefore, refer to "Center Exhaust Pipe" for removal procedure. <Ref. to EX(H4SO)-7, REMOVAL, Center Exhaust Pipe.>

#### B: INSTALLATION

The rear catalytic converter is integrated into center exhaust pipe as one unit; therefore, refer to "Center Exhaust Pipe" for installation procedure. <Ref. to EX(H4SO)-7, INSTALLATION, Center Exhaust Pipe.>

#### C: INSPECTION

- 1) Check the connections and welds for exhaust leaks.
- 2) Make sure there are no holes or rusting.