

12. Fuel Injector


A: REMOVAL

1. RH SIDE

1) Release the fuel pressure.

<Ref. to FU(H4SO)-44, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>

2) Disconnect the ground cable from battery.



3) Open the fuel filler flap lid, and remove the fuel filler cap.

4) Remove the air intake duct and air cleaner case.

<Ref. to IN(H4SO)-7, REMOVAL, Air Intake Duct.>

<Ref. to IN(H4SO)-5, REMOVAL, Air Cleaner Case.>


5) Remove the power steering pump and reservoir tank.

(1) Remove the front side V-belt. <Ref. to ME(H4SO)-37, REMOVAL, V-belt.>


(2) Remove the bolts which hold the power steering pipes onto the intake manifold protector RH.

NOTE:


Do not disconnect the power steering hose.




(3) Remove the bolts which install the power steering pump to the bracket.




(4) Disconnect the connector from power steering pump switch (A).



(5) Remove the reservoir tank from the bracket by pulling it upward.




(6) Place the power steering pump and tank on the right side wheel apron.




6) Remove the spark plug cords from spark plugs (#1 and #3 cylinders).


7) Remove the fuel pipe protector RH.




5) Remove the fuel pipe protector LH.




8) Disconnect the connectors (A) from fuel injector.
9) Remove the harness band (B) which holds the engine harness to injector pipe.




6) Disconnect the connectors (A) from fuel injector.
7) Remove the harness band (B) which holds the engine harness to injector pipe.



10) Remove the bolt which holds fuel injector pipe onto intake manifold.



8) Remove the bolt which holds fuel injector pipe onto intake manifold.



11) Remove the fuel injector while lifting up the fuel injector pipe.

2. LH SIDE


1) Release the fuel pressure.

<Ref. to FU(H4SO)-44, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.>

2) Remove the battery. <Ref. to SC(H4SO)-19, REMOVAL, Battery.>

3) Open the fuel filler flap lid, and remove the fuel filler cap.

4) Remove the spark plug cords from spark plugs (#2 and #4 cylinders).



9) Remove the fuel injector while lifting up the fuel injector pipe.

Fuel Injector

FUEL INJECTION (FUEL SYSTEMS)


B: INSTALLATION

1. RH SIDE

Install in the reverse order of removal.

NOTE:


Use new O-rings.



- (A) O-ring
- (B) O-ring
- (C) Fuel injector
- (D) O-ring


Tightening torque:

19 N·m (1.9 kgf·m, 14.0 ft-lb)



Tightening torque:

19 N·m (1.9 kgf·m, 14.0 ft-lb)




2. LH SIDE

Install in the reverse order of removal.

NOTE:


Use new O-rings.



- (A) O-ring
- (B) O-ring
- (C) Fuel injector
- (D) O-ring


Tightening torque:

6.4 N·m (0.65 kgf·m, 4.7 ft-lb)



Tightening torque:

19 N·m (1.9 kgf·m, 14.0 ft-lb)



Tightening torque:

19 N·m (1.9 kgf·m, 14.0 ft-lb)

