

### 10. Fuel Sub Level Sensor

#### A: REMOVAL

Refer to the FU(H4DOTC) section for removal procedure. <Ref. to FU(H4DOTC)-61, REMOVAL, Fuel Sub Level Sensor.>

#### B: INSTALLATION

Refer to the FU(H4DOTC) section for installation procedure. <Ref. to FU(H4DOTC)-61, INSTALLATION, Fuel Sub Level Sensor.>