



## 35.Oil Pump Housing

### A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-37, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch assembly. <Ref. to 4AT-69, REMOVAL, Torque Converter Clutch Assembly.>
- 3) Remove the input shaft.



- 4) Lift-up the lever on the rear side of transmission harness connector, and then disconnect it from the stay.
- 5) Disconnect the inhibitor switch connector from the stay.
- 6) Remove the oil charger pipe. <Ref. to 4AT-68, REMOVAL, Oil Charger Pipe.>
- 7) Remove the ATF cooler inlet and outlet pipes. <Ref. to 4AT-65, REMOVAL, ATF Cooler Pipe and Hose.>
- 8) Separate the converter case and transmission case. <Ref. to 4AT-89, REMOVAL, Converter Case.>
- 9) Separate the transmission case and extension case section. <Ref. to 4AT-70, REMOVAL, Extension Case.>
- 10) Remove the reduction drive gear. <Ref. to 4AT-84, REMOVAL, Reduction Drive Gear.>
- 11) Remove the reduction driven gear. <Ref. to 4AT-82, REMOVAL, Reduction Driven Gear.>
- 12) Loosen the oil pump housing mounting bolts.




- 13) Place two wooden blocks on the workbench, and stand the transmission case with the rear end facing down.

### CAUTION:


**Be careful not to scratch the rear mating surface of transmission case.**

### NOTE:

Check the height of the wooden blocks to avoid damaging the parking rod protruding from the mating surface, and the drive pinion.



- 14) Remove the oil pump housing and adjusting thrust washer.




(A) Oil pump housing

### B: INSTALLATION

- 1) Secure the oil pump housing with two nuts and a bolt.

### Tightening torque:

**42 N·m (4.3 kgf-m, 31 ft-lb)**




(A) Oil pump housing

# Oil Pump Housing

## AUTOMATIC TRANSMISSION

- 2) Install the converter case to the transmission case. <Ref. to 4AT-69, INSTALLATION, Torque Converter Clutch Assembly.>
- 3) Install the reduction driven gear. <Ref. to 4AT-82, INSTALLATION, Reduction Driven Gear.>
- 4) Install the reduction drive gear. <Ref. to 4AT-84, INSTALLATION, Reduction Drive Gear.>
- 5) Join the transmission case and the extension case. <Ref. to 4AT-70, INSTALLATION, Extension Case.>
- 6) Insert the inhibitor switch and transmission connector to the stay.




- (A) Transmission harness ASSY  
(B) Inhibitor switch harness

- 7) Install the ATF cooler pipe. <Ref. to 4AT-66, INSTALLATION, ATF Cooler Pipe and Hose.>
- 8) Install the oil charger pipe along with the O-ring. <Ref. to 4AT-68, INSTALLATION, Oil Charger Pipe.>
- 9) Insert the input shaft while rotating it lightly by hand, and then check the amount of protrusion.

### Normal protrusion A:

50 — 55 mm (1.97 — 2.17 in)




- 10) Install the torque converter clutch assembly. <Ref. to 4AT-69, INSTALLATION, Torque Converter Clutch Assembly.>
- 11) Install the transmission assembly to the vehicle. <Ref. to 4AT-40, INSTALLATION, Automatic Transmission Assembly.>

## C: DISASSEMBLY


### 1. OIL PUMP COVER

- 1) Remove the four seal rings.




- (A) Seal ring

- 2) Remove the installation bolt. Then remove the cover by lightly tapping the end of starter shaft.



- (A) Oil pump cover  
(B) Oil pump housing


- 3) Remove the oil pump inner and outer rotors.



- (A) Oil pump rotor inner rotor  
(B) Oil pump outer rotor


## 2. OIL SEAL RETAINER

1) Remove the oil seal retainer.




- (A) Oil seal retainer
- (B) Drive pinion shaft

2) Remove the O-ring.



- (A) O-ring

3) Remove the oil seal from the oil seal retainer.




- (A) Oil seal
- (B) Oil seal retainer

## D: ASSEMBLY

### 1. OIL PUMP COVER

1) Install the oil pump rotor assembly to oil pump housing.




- (A) Oil pump rotor inner rotor
- (B) Oil pump outer rotor

2) Align both pivots with the pivot holes of the cover, and then install the oil pump cover while being careful not to apply excessive force to the pivots.

**Tightening torque:**

**25 N·m (2.5 kgf-m, 18.1 ft-lb)**



- (A) Oil pump cover
- (B) Oil pump housing

3) After assembling, turn the oil pump shaft to check for smooth rotation of rotor.


# Oil Pump Housing

## AUTOMATIC TRANSMISSION

4) Install the oil seal retainer and new seal rings. After installing, adjust the tooth contact with the drive pinion backlash. <Ref. to 4AT-95, ADJUSTMENT, Oil Pump Housing.>

### CAUTION:


There are two types of seals. They are identified by color. Install at the proper positions by referring to the figure.



- (A) Seal ring (Black)
- (B) Seal ring (Brown)


## 2. OIL SEAL RETAINER

1) Install two new oil seals to the oil seal retainer in the proper direction using the ST.  
ST 499247300 INSTALLER



- (A) Oil seal
- (B) Oil seal retainer

2) Install a new O-ring to the oil seal retainer using vaseline.




- (A) O-ring

3) Install the oil seal being careful not to damage oil seal lip, and secure it using three bolts.

### Tightening torque:

**7 N·m (0.7 kgf-m, 5.1 ft-lb)**




- (A) Oil seal retainer
- (B) Drive pinion shaft

## E: INSPECTION

- 1) Check the seal ring and oil seal for breaks and damage.
- 2) Check other parts for dents or faults.
- 3) Oil pump rotor assembly selection
  - (1) Tip clearance  
Install the oil pump inner rotor and outer rotor to the oil pump. With rotor gears facing each other, measure the crest-to-crest clearance.


**Tip clearance:**  
**0.02 — 0.15 mm (0.0008 — 0.0059 in)**



- (A) Thickness gauge
- (B) Oil pump rotor inner rotor
- (C) Oil pump outer rotor

- (2) Side clearance  
Set a depth gauge to the oil pump housing, then measure the oil pump housing-to-oil pump rotor clearance.

**Side clearance:**  
**0.02 — 0.04 mm (0.0008 — 0.0016 in)**



- (A) Depth gauge
- (B) Oil pump rotor inner rotor
- (C) Oil pump outer rotor


- (3) If the depth and side clearance are out of specification, replace the oil pump rotor assembly.

Oil pump rotor assembly	
Part No.	Thickness mm (in)
15008AA060	11.37 — 11.38 (0.4476 — 0.4480)
15008AA070	11.38 — 11.39 (0.4480 — 0.4484)
15008AA080	11.39 — 11.40 (0.4484 — 0.4488)

Inspect the total end play, and adjust it to be within the standard value. <Ref. to 4AT-95, ADJUSTMENT, Oil Pump Housing.>


## F: ADJUSTMENT

- 1) Measure the distance “L” from the end of ST to the high clutch drum concave section using the ST. ST 398643600 GAUGE



- 2) Measure the distance from the oil pump housing mating surface to the end surface of the ST using the ST.

ST 398643600 GAUGE



# Oil Pump Housing


## AUTOMATIC TRANSMISSION

### 3) Calculation of total end play

Select the suitable thrust needle bearing from the table below so that clearance C will be within 0.25 to 0.55 mm (0.0098 to 0.0217 in).

$$C = (L + G) - \varnothing$$

C	Clearance between concave section of high clutch and end of clutch drum support
L	Distance from the transmission case mating surface to concave portion of high clutch
G	Gasket thickness [0.28 mm (0.0110 in)]
$\varnothing$	Height from the oil pump housing mating surface to the upper surface of the cover for the oil pump having the thrust needle bearing.



Thrust needle bearing	
Part No.	Thickness mm (in)
806528050	4.1 (0.161)
806528060	4.3 (0.169)
806528070	4.5 (0.177)
806528080	4.7 (0.185)
806528090	4.9 (0.193)
806528100	5.1 (0.201)

4) After completing the end play adjustment, insert the bearing race in the high clutch race. Apply vaseline to install the thrust needle bearing to oil pump cover.

5) After correctly installing the new gasket to the case mating surface, carefully install the oil pump housing assembly. Be careful to avoid hitting the drive pinion against the inside of case.

6) Install both parts with dowel pins aligned. Make sure there is no clearance at the mating surface.