

8. Inspection Mode

A: PROCEDURE

Recreate the condition by referring to the fault conditions described in the check list.