

Basic Diagnostic Procedure

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

1. Basic Diagnostic Procedure

A: PROCEDURE

Step	Check	Yes	No
1 CHECK MALFUNCTION INDICATOR LIGHT. Check that malfunction indicator light illuminates.	Does the malfunction indicator light illuminate?	Go to step 5.	Go to step 2.
2 CHECK CRUISE INDICATOR LIGHT. Make sure the cruise indicator light blinks.	Does the cruise indicator light blink?	Go to step 5.	Go to step 3.
3 CHECK CRUISE CONTROL MAIN SWITCH OPERATION. Check cruise control main switch operation. (Ensure the cruise indicator light illuminates.)	Is the cruise control main switch turned on? (Does the cruise indicator light illuminate?)	Go to step 4.	Go to symptom 1. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnostics with Phenomenon.>
4 CHECK CRUISE CONTROL SET OPERATION. Check the cruise control set operation.	Can the cruise control be set while driving at more than 40 km/h (25 MPH)?	Go to step 6.	Go to step 5.
5 PERFORM CRUISE CONTROL CANCEL CONDITIONS DIAGNOSIS. Perform the cruise cancel conditions diagnosis.	Is DTC displayed?	Go to "List of Diagnostic Trouble Code (DTC)." <Ref. to CC(ETC)(diag)-12, List of Diagnostic Trouble Code (DTC).>	Go to symptom 2. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnostics with Phenomenon.>
6 CHECK VEHICLE SPEED IS HELD WITHIN SET SPEED. Make sure the vehicle speed is held within set speed.	Is the vehicle speed kept within setting speed ± 3 km/h (± 2 MPH) ? (Make sure that on a level road.)	Go to step 7.	Go to symptom 3. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnostics with Phenomenon.>
7 CHECK RESUME/ACCEL OPERATION. Check the RESUME/ACCEL switch operation.	Does the vehicle speed increase or return to set speed after RESUME/ACCEL switch has been pressed?	Go to step 8.	Go to symptom 4. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnostics with Phenomenon.>
8 CHECK SET/COAST OPERATION. Check the SET/COAST switch operation.	Does the vehicle speed decrease after SET/COAST switch has been pressed?	Go to step 9.	Go to symptom 5. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnostics with Phenomenon.>
9 CHECK CANCEL OPERATION. Check the CANCEL switch operation.	Is the cruise control released after CANCEL switch has been pressed?	Go to step 10.	Go to symptom 6. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnostics with Phenomenon.>

Basic Diagnostic Procedure

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
10 CHECK CRUISE CONTROL RELEASE OPERATION. Check the cruise control release operation.	Is the cruise control released after brake pedal has been depressed?	Go to step 11.	Go to symptom 7. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnos- tics with Phenom- enon.>
11 CHECK CRUISE CONTROL RELEASE OPERATION. Check the cruise control release operation.	Is the cruise control released after depressing the clutch pedal?	Go to step 12.	Go to symptom 8. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnos- tics with Phenom- enon.>
12 CHECK CRUISE CONTROL RELEASE OPERATION. Check the cruise control release operation.	Is the cruise control released after shifting to the neutral position?	Finish the diagno- sis.	Go to symptom 9. <Ref. to CC(ETC)(diag)-9, SYMPTOM CHART, Diagnos- tics with Phenom- enon.>