

2. Front Grille

A: REMOVAL

- 1) Open the front hood.
- 2) Remove the front bumper. <Ref. to EI-21, RE-MOVAL, Front Bumper.>
- 3) Remove the upper six clips of front grille.




4) Pull the front grille out toward the front of the vehicle.



B: INSTALLATION

1) Install in the reverse order of removal.



NOTE:

Be careful with the hook position.