


### 22.Rear Gate Trim

#### A: REMOVAL

**CAUTION:**

**Be careful not to damage the clips or their holes.**

Remove the rear gate inner handle (A) from the rear gate, and remove the trim panel.



#### B: INSTALLATION

Install in the reverse order of removal.