



Electrical Component Location

HVAC SYSTEM (AUTO A/C) (DIAGNOSTICS)

3. Electrical Component Location

A: LOCATION

1. ENGINE COMPARTMENT







AC-01368

- | | | |
|---------------------------------|-----------------------------|--------------------|
| (1) A/C compressor | (3) A/C relay (Turbo model) | (5) Ambient sensor |
| (2) A/C relay (Non-turbo model) | (4) Pressure switch | |

Electrical Component Location

HVAC SYSTEM (AUTO A/C) (DIAGNOSTICS)

2. PASSENGER COMPARTMENT



SUBARU.

AC-01189

- | | | |
|------------------------|--------------------------|---------------------------|
| (1) Mode door actuator | (4) Intake door actuator | (6) Evaporator sensor |
| (2) In-vehicle sensor | (5) Blower motor | (7) Air mix door actuator |
| (3) Sunload sensor | | |