


7. Passenger's Airbag ON/OFF Indicator Light Illumination Pattern

A: INSPECTION



(1) Passenger's airbag ON indicator light	(4) Ignition switch	(9) Adult
	(5) Light OFF	(10) OFF
(2) Passenger's airbag OFF indicator light	(6) Light ON	(11) ON
	(7) Empty	(12) Approx. 6 sec.
(3) Occupant seating	(8) Child	(13) Approx. 2 sec.

NOTE:

After the ignition switch is ON, the passenger's airbag ON/OFF indicator light for both ON and OFF come on for approximately 6 seconds then turn off for approximately 2 seconds, and then either ON or OFF will be illuminated for occupants.