


24.Body Integrated Unit

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the instrument panel lower cover. <Ref. to EI-38, REMOVAL, Instrument Panel Assembly.>
- 3) Remove the nut, then disconnect the connector to remove the body integrated unit.



B: INSTALLATION

Install in the reverse order of removal.