



### 27. Immobilizer Antenna

#### A: REMOVAL

- 1) Disconnect the ground cable from the battery.
- 2) Remove the instrument panel lower cover. <Ref. to EI-38, REMOVAL, Instrument Panel Assembly.>
- 3) Remove the screws, and detach the upper column cover and lower column cover.



- 4) Disconnect the immobilizer antenna connector (A) from body harness.
- 5) Remove the screws and detach the immobilizer antenna (B).



#### B: INSTALLATION

Install in the reverse order of removal.

# SUNROOF/T-TOP/CONVERTIBLE TOP (SUNROOF)

**SR** 

---

	Page
1. General Description .....	2
2. Sunroof Control System .....	4
3. Sunroof Lid .....	5
4. Sunroof Assembly .....	6
5. Sunroof Motor .....	8
6. Sunroof Switch .....	9