


## 2. Air Cleaner Element

### A: REMOVAL

1) Remove the clips (B) on air cleaner case.




2) Remove the air cleaner element.

### B: INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Fasten with a clip after inserting the lower tab of case.



### C: INSPECTION

Replace if excessively damaged or dirty.