



7. Body Integrated Unit

A: REMOVAL


- 1) Disconnect the ground cable from battery.



- 2) Remove the lower cover.
- 3) Remove the knee bolster.



- 4) Disconnect the connector from body integrated unit.
- 5) Remove the body integrated unit.



B: INSTALLATION

Install in the reverse order of removal.