

General Diagnostic Table

CONTROL SYSTEMS

9. General Diagnostic Table

A: INSPECTION

Symptom	Problem parts
Shift lock does not function.	• Stop light switch • Shift lock solenoid • Body integrated unit
Shift lock cannot be released.	• Stop light switch • Shift lock solenoid • Body integrated unit • Inhibitor switch
Key interlock does not function.	• Key warning switch • "P" range switch • Key lock solenoid • Body integrated unit
Key interlock cannot be released.	• Key warning switch • "P" range switch • Key lock solenoid • Body integrated unit
Starter does not run.	• Inhibitor switch • Select cable • Starter circuit
Back-up light does not illuminate.	• Inhibitor switch • Select cable • Back-up light circuit
Gear can be shifted from "N" to "R" during driving.	• Shift lock solenoid • TCM

AUTOMATIC TRANSMISSION

4AT

	Page
1. General Description	2
2. Automatic Transmission Fluid	28
3. Differential Gear Oil	30
4. Road Test	31
5. Stall Test	32
6. Time Lag Test	33
7. Line Pressure Test	34
8. Transfer Clutch Pressure Test	36
9. Automatic Transmission Assembly	37
10. Transmission Mounting System	44
11. Extension Case Oil Seal	46
12. Differential Side Retainer Oil Seal	47
13. Inhibitor Switch	48
14. Front Vehicle Speed Sensor	52
15. Rear Vehicle Speed Sensor	55
16. Torque Converter Turbine Speed Sensor	56
17. Control Valve Strainer	57
18. Control Valve Body	59
19. Air Bleeding of Control Valve	62
20. ATF Filter	63
21. Transmission Control Module (TCM)	64
22. ATF Cooler Pipe and Hose	65
23. Air Breather Hose	67
24. Oil Charger Pipe	68
25. Torque Converter Clutch Assembly	69
26. Extension Case	70
27. Transfer Clutch	74
28. Multi-plate Clutch	80
29. Rear Drive Shaft	81
30. Reduction Driven Gear	82
31. Reduction Drive Gear	84
32. Center Differential Carrier	86
33. Parking Pawl	88
34. Converter Case	89
35. Oil Pump Housing	91
36. Drive Pinion Shaft Assembly	97
37. Front Differential Assembly	102
38. AT Main Case	108
39. Transmission Control Device	129