
52. Harness Components Location

A: LOCATION



- (1) Front wiring harness
- (2) Engine wiring harness
- (3) Bulkhead wiring harness
- (4) Instrument panel wiring harness
- (5) Front door cord (RH)
- (6) Rear door cord (RH)
- (7) Rear wiring harness
- (8) Roof cord
- (9) Fuel tank cord
- (10) Rear gate cord

- (11) Rear gate cord 2
- (12) Rear door cord (LH)
- (13) Front door cord (LH)
- (14) Transmission cord