

55. Bulkhead Wiring Harness (In Compartment)

A: LOCATION

- Bulkhead wiring harness

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B2	5	Gray	C-2		HID relay
B30	25	★	C-1	D1	Front door cord LH
B31	12	Yellow	D1	AB1	Airbag wiring harness (Vehicles prior to V.I.N. 733000)
	6				Airbag wiring harness (Vehicles after V.I.N. 733001)
B32	3	Black	B-3		Turn signal and hazard unit
B33	8	★	D-1		Airbag joint connector (Vehicles prior to V.I.N. 733000)
B34	2	Yellow	C-4		Side airbag
B36	24	★	C-1	i1	Instrument panel wiring harness
B38	32	★	B-1	i3	
B40	16	Black	C-3		Data link connector
B41	2	★	C-1		Power window circuit breaker
B46	4	★	B-5		Fuel pump relay
B47	6	Brown	B-5		Main relay
B50	4	★	C-1		Blower fan relay
B51	8	Blue	C-1		Fuse & relay box (F/B)
B52	7	★	C-1		
B54	35	★	B-2		Transmission control module
B55	35	★	B-2		
B59	5	Gray	B-2		Interrupt relay (Security)
B61	8	Black	B-1	F44	Front wiring harness
B62	24	Black	B-2	F45	
B65	4	Black	B-2		Stop light & brake switch
B69	4	★	B-3		Parking switch
B70	18	★	B-3		Combination switch
B71	17	★	B-3		
B72	4	Blue	C-2		Ignition switch
B73	6	★	C-3		Key lock solenoid & key warning switch
B75	2	Green	C-2	B76	Test mode connector
B76	2	Green	C-2	B75	
B77	10	Brown	B-3		Mode actuator (Auto A/C)
B86	6	Black	B-4		Blower resistor (NA model)

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B87	2	★	B-4		Blower motor (Manual A/C)
	6	★	B-4		Blower motor (Auto A/C)
B90	8	★	B-5	R50	Roof cord
B91	4	★	B-4		Intake actuator
B95	4	Brown	B-4		Diode (Daytime running light)
B96	10	★	B-4		Daytime running light control module
B100	20	Blue	B-2	F2	Front wiring harness
B101	25	★	B-5	D11	Front door cord RH
B102	5	Black	B-5		Daytime running light relay
B103	4	Blue	B-5		High-beam relay (Daytime running light)
B104	4	Red	C-1		Rear accessory relay
B106	2	★	B-2		Clutch switch (MT model)
B107	2	Blue	B-2		Clutch switch (MT model with cruise control)
B108	2	Black	B-1	F46	Front wiring harness
B112	2	Black	B-3		Diode (Front fog light)
B112	4	Brown	B-3		Diode (Front fog light & shift lock diode)
B117	6	★	C-4		AT select lever
B119	4	★	C-4		Front accessory power supply socket
B122	8	★	C-4		Shield and sensor joint connector
B125	1	Green	B-5	B126	Line end check connector
B126	1	Green	B-5	B125	
B132	6	★	C-2		Headlight beam leveler switch (HID model)
B134	34	★	C-4		Engine control module
B135	35	★	B-4		
B136	35	★	B-4		
B137	31	★	B-4		
B141	26	Gray	B-2		Immobilizer Control Module
B142	2	★	B-2		Immobilizer antenna (Turbo model)
B152	12	★	C-1		Fuse & relay box (F/B)
B158	10	Gray	C-1		
B160	6	Gray	C-2		Front fog light switch

Bulkhead Wiring Harness (In Compartment)

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B173	1	★	C-1		Ignition power supply connector
B176	26	Gray	B-5		Keyless entry control module
B177	2	★	B-5		Wiper deicer
B193	8	Black	C-2		Wiper deicer switch
B194	2	Black	C-1		Joint connector (Key-lock) (Turbo model)
B195	2	Black	C-1		
B198	1	★	B-4	B199	Joint ground connector
B199	1	★	B4	B198	
B200	32	★	B-2	F74	Front wiring harness
B201	24	Black	C-4	i40	Instrument panel wiring harness
B202	24	★	C-4	i41	Instrument panel wiring harness (Auto A/C)
B202	20	★	C-4	i41	Instrument panel wiring harness (Manual A/C)
B225	8	Black	C-2		Fuse (Relay block)
	5	Black	C-2		Ignition relay (Relay block)
	5	Black	C-2		Power window relay (Relay block)
	5	Black	C-2		Front fog light relay (Relay block)
	5	Black	C-2		Starter interlock relay (Relay block)
	5	Black	C-2		Wiper deicer & Mirror heater relay (Relay block)
	5	Black	C-2		Seat heater relay (Relay block)
B230	6	Black	C-4		Yaw rate & lateral G sensor (with VDC)
B231	4	★	C-3		Steering angle sensor (with VDC)
B236	8	★	C-3		Steering roll connector
B256	3	★	B-4		Evaporator thermo switch
B271	12	Blue	C-1		Fuse & relay box (F/B) Body integrated unit
B280	16	Blue	C-3		
B281	20	Gray	C-3		
B292	3	★	C-4		ABS G sensor
B309	4	Black	B-4		Electronic throttle control relay
B310	83	Black	B-3		VDC control module
B312	6	★	B-3		VDC shield joint connector
B313	4	Brown			HID diode

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B315	6	Black	B-3		Accelerator position sensor
B318	6	Brown	C-2		VDC OFF switch
B327	5	Gray	B-4		A/F & Oxygen sensor relay (Non-turbo model)
B348	8	★	B-4		Impact sensor

★: White or natural color

• Airbag wiring harness

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB1	12	Yellow	D-1	B31	Bulkhead wiring harness (Vehicles prior to V.I.N. 733000)
	6				Bulkhead wiring harness (Vehicles after V.I.N. 733001)
AB2	4	Yellow	C-3		Airbag module (Driver)
AB3	28	Yellow	C-4		Airbag control module
AB4	4	Yellow	B-5		Airbag module (Passenger)
AB13	2	Yellow	C-1		Front sub sensor LH

